

お読み替えガイド (Hitachi Block Storage Driver for OpenStack v06.3.0)

本製品に関するユーザーズガイドは、主に国外向けに英語で作成したものを参照いただきます。その際、ユーザーズガイドに記載されている一部内容は、本書に示す通り、読み替えてご覧ください。

1. サポート対象

次の表をご確認ください。

#	お読み替え前	お読み替え後
1	Hitachi Virtual Storage Platform N400, N600, N800	Hitachi Virtual Storage Platform N400, N600, N800 は日本国外でのみサポート しています。
2	https://support.HitachiVantara.com/en_us/interoperability.html	次の URL をご参照ください。 http://www.hitachi.co.jp/products/it/unified/adapters/hbsd/
3	https://www.HitachiVantara.com/en-us/products-solutions/application-solutions/hitachi-and-openstack.html	次の URL をご参照ください。 http://www.hitachi.co.jp/products/it/unified/adapters/hbsd/

2. 使い方

お読み替え事項はありません。

3. 制限事項

お読み替え事項はありません。

4. その他

次の表をご確認ください。

#	お読み替え前	お読み替え後
1	Command Control Interface(CCI)	RAID Manager
2	<p>Referenced documents</p> <p>The documents below are referenced in this document or contain more information about the features described in this document.</p> <p>Hitachi Vantara documents</p> <p>Hitachi Command Suite Configuration Manager REST API: REST API Reference Guide, MK-92HC229 Hitachi Virtual Storage Platform F series and G</p>	<p>参考資料を次に示します。</p> <p>■Hitachi Command Suite Configuration Manager REST API リファレンスガイド</p> <p>Hitachi Virtual Storage Platform F1500 and Hitachi Virtual Storage Platform G1000,G1500: ■global-active device ユーザガイド</p> <p>Hitachi Virtual Storage Platform F350, F370, F700, F900 and Hitachi Virtual Storage Platform</p>

<p>series:</p> <ul style="list-style-type: none"> ■ Global-Active Device User Guide, MK-97HM85037 ■ Thin Image User Guide, MK-97HM85032 ■ Universal Replicator User Guide, MK-97HM85035 <p>Hitachi Virtual Storage Platform F1500 and Hitachi Virtual Storage Platform G1000,G1500: Provisioning Guide for Open Systems, MK-92RD8014</p> <p>Hitachi Virtual Storage Platform F400, F600, F800 and Hitachi Virtual Storage Platform G200, G400, G600, G800: Provisioning Guide, MK-94HM8014</p> <p>Hitachi Virtual Storage Platform F350, F370, F700, F900 and Hitachi Virtual Storage Platform G350, G370, G700, G900:</p> <ul style="list-style-type: none"> ■ Hitachi Storage Advisor Embedded Guide, MK-97HM85022 ■ Provisioning Guide, MK-97HM85026 <p>Hitachi Vantara Support Connect, https://knowledge.hitachivantara.com/Documents</p>	<p>G130, G150, G350, G370, G700, G900: ■global-active device ユーザガイド</p> <p>■Thin Image ユーザガイド</p> <p>■Universal Replicator ユーザガイド</p> <p>Hitachi Virtual Storage Platform F1500 and Hitachi Virtual Storage Platform G1000,G1500: ■オープンシステム構築ガイド</p> <p>Hitachi Virtual Storage Platform F400, F600, F800 and Hitachi Virtual Storage Platform G100, G200, G400, G600, G800: ■システム構築ガイド</p> <p>Hitachi Virtual Storage Platform F350, F370, F700, F900 and Hitachi Virtual Storage Platform G130, G150, G350, G370, G700, G900: ■Hitachi Storage Advisor Embedded ガイド</p> <p>■システム構築ガイド</p> <p>関連するドキュメントは次の URL をご参照ください。 http://itdoc.hitachi.co.jp/Pages/document_list/index.html</p>
<p>Related documents</p> <p>The documents below are referenced in this document or contain more information about the features described in this document.</p> <p>Hitachi Vantara documents</p> <p>Hitachi Virtual Storage Platform F1500 and Hitachi Virtual Storage Platform G1000,G1500:</p> <ul style="list-style-type: none"> ■ Hardware Guide, MK-92RD8007 ■ System Administrator Guide, MK-92RD8016 <p>3 Hitachi Virtual Storage Platform F400, F600, F800 and Hitachi Virtual Storage Platform G200, G400, G600, G800:</p> <ul style="list-style-type: none"> ■ Hardware Reference Guide: Hitachi Virtual Storage Platform F400, F600, MK-94HM8045 ■ Hardware Reference Guide: Hitachi Virtual Storage Platform F800, MK-94HM8046 ■ Hardware Reference Guide: Hitachi Virtual Storage Platform G200, MK-94HM8020 ■ Hardware Reference Guide: Hitachi Virtual Storage Platform G400, G600, MK-94HM8022 ■ Hardware Reference Guide: Hitachi Virtual 	<p>関連するドキュメントを次に示します。</p> <p>Hitachi Virtual Storage Platform F1500 and Hitachi Virtual Storage Platform G1000,G1500: ■ハードウェアリファレンスガイド</p> <p>■Hitachi Device Manager - Storage Navigator ユーザガイド</p> <p>Hitachi Virtual Storage Platform F400, F600, F800 and Hitachi Virtual Storage Platform G100, G200, G400, G600, G800: ■Hitachi Virtual Storage Platform G400, G600, Hitachi Virtual Storage Platform F400, F600 ユーザガイド</p> <p>■Hitachi Virtual Storage Platform G800,Hitachi Virtual Storage Platform F800 ユーザガイド</p> <p>■Hitachi Virtual Storage Platform G200 ユーザガイド</p> <p>■Hitachi Virtual Storage Platform G400, G600, Hitachi Virtual Storage Platform F400, F600 ユーザガイド</p>

	<p>Storage Platform G800, MK-94HM8026</p> <ul style="list-style-type: none"> ■ System Administrator Guide, MK-94HM8016 <p>Hitachi Virtual Storage Platform F350, F370, F700, F900 and Hitachi Virtual Storage Platform G350, G370, G700, G900:</p> <ul style="list-style-type: none"> ■ Hardware Reference Guide: Hitachi Virtual Storage Platform F350 and F370, MK-97HM85016 ■ Hardware Reference Guide: Hitachi Virtual Storage Platform F700, MK-97HM85017 ■ Hardware Reference Guide: Hitachi Virtual Storage Platform F900, MK-97HM85018 ■ Hardware Reference Guide: Hitachi Virtual Storage Platform G350 and G370, MK-97HM85012 ■ Hardware Reference Guide: Hitachi Virtual Storage Platform G700, MK-97HM85013 ■ Hardware Reference Guide: Hitachi Virtual Storage Platform G900, MK-97HM85014 ■ System Administrator Guide, MK-97HM85028 	<ul style="list-style-type: none"> ■Hitachi Virtual Storage Platform G800,Hitachi Virtual Storage Platform F800 ユーザガイド <p>Hitachi Virtual Storage Platform F350, F370, F700, F900 and Hitachi Virtual Storage Platform G130, G150, G350, G370, G700, G900:</p> <ul style="list-style-type: none"> ■システム構築ガイド ■Thin Image ユーザガイド ■システム管理者ガイド ■ハードウェアリファレンスガイド
4	<p>Comments</p> <p>Please send us your comments on this document to doc.comments@hitachivantara.com. Include the document title and number, including the revision level (for example, -07), and refer to specific sections and paragraphs whenever possible. All comments become the property of Hitachi Vantara Corporation.</p>	<p>本ドキュメントに関するご意見は、当社営業担当にご連絡ください。</p>
5	<p>Getting help</p> <p>Hitachi Vantara Support Connect is the destination for technical support of products and solutions sold by Hitachi Vantara. To contact technical support, log on to Hitachi Vantara Support Connect for contact information: https://support.hitachivantara.com/en_us/contact-us.html.</p> <p>Hitachi Vantara Community is a global online community for Hitachi Vantara customers, partners, independent software vendors, employees, and prospects. It is the destination to get answers, discover insights, and make connections. Join the conversation today!</p> <p>Go to community.hitachivantara.com, register, and complete your profile.</p>	<p>本製品のサポート条件については、次の URL 内のサポート条件をご確認ください。</p> <p>http://www.hitachi.co.jp/products/it/unified/adapter/hbsdof/</p> <p>サポート契約をされているお客様は、次の連絡先にお問い合わせください。</p> <p>日立サポートサービス : http://www.hitachi-support.com/</p> <p>サポート契約をされていないお客様は、当社営業担当にお問い合わせください。</p>
6	<p>Release notes</p> <p>Read the release notes before installing and using this product. They may contain requirements or restrictions that are not fully</p>	<p>次の URL をご参照ください。</p> <p>http://www.hitachi.co.jp/products/it/unified/adapter/hbsdof/</p>

	<p>described in this document or updates or corrections to this document. Release notes are available on Hitachi Vantara Support</p> <p>Connect: https://knowledge.hitachivantara.com/Documents.</p>	
7	<p>Hitachi Vantara Corporate Headquarters 2535 Augustine Drive Santa Clara, CA 95054 USA HitachiVantara.com community.HitachiVantara.com Contact Information USA: 1-800-446-0744 Global: 1-858-547-4526 HitachiVantara.com/contact</p>	<p>株式会社 日立製作所 東京都千代田区丸の内一丁目 6 番 6 号</p>

免責事項、他社商標、輸出管理について

免責事項

本書の内容の一部、または全部を無断で複製することはできません。

本書の内容については、将来予告なしに変更することがあります。

本書に記載されている以外の方法で本製品を操作した結果、たとえ本製品がインストールされているお客様所有のコンピュータに何らかの障害が発生しても、当社は一切責任を負いかねますので、あらかじめご了承ください。

本製品のサポートサービスに関する詳細は、当社営業担当にお問い合わせください。

他社商標

すべてのブランド名および製品名は個々の所有者の登録商標または商標です。なお、本文中では®および™は明記しておりません。

輸出管理について

このドキュメントにより、提供された技術やプログラムまたは購入した製品を輸出(または非居住者への提供)する場合は、「外国為替および外国貿易法」その他適用される法令を遵守してください。