

お読み替えガイド (Hitachi Block Storage Driver for OpenStack v09.0.1)

本製品に関するユーザーズガイドは、主に国外向けに英語で作成したものを参照いただきます。その際、ユーザーズガイドに記載されている一部内容は、本書に示す通り、読み替えてご覧ください。

1. サポート対象

次の表をご確認ください。

#	お読み替え前	お読み替え後
1	Hitachi Virtual Storage Platform N400, N600, N800	Hitachi Virtual Storage Platform N400, N600, N800 は日本国外でのみサポートしています。
2	For details about the supported storage systems, see the Hitachi Block Storage OpenStack driver support matrix at: https://support.HitachiVantara.com/en_us/interoperability.html .	対応するストレージシステムの詳細は、Hitachi Vantara Support サイトにある OpenStack のサポート一覧を参照してください。 https://support.HitachiVantara.com/en_us/interoperability.html . また、 Hitachi Virtual Storage Platform G150 Hitachi Virtual Storage Platform E390, E390H を国内向けに追加でサポートしています。

2. 使い方

お読み替え事項はありません。

3. 制限事項

お読み替え事項はありません。

4. その他

次の表をご確認ください。

#	お読み替え前	お読み替え後
1	Command Control Interface(CCI)	RAID Manager
2	Referenced documents The documents below are referenced in this document or contain more information about the features described in this document. Hitachi Vantara documents Hitachi Command Suite Configuration Manager	参考資料を次に示します。 ■Hitachi Command Suite Configuration Manager REST API リファレンスガイド ■Hitachi Storage Advisor Embedded ガイド

<p>REST API: REST API Reference Guide, MK-92HC229 Hitachi Ops Center API Configuration Manager REST API Reference Guide, MK-99CFM000 Hitachi Storage Advisor Embedded Guide, MK-97HM85022</p> <p>Global-Active Device User Guide</p> <p>Hitachi Virtual Storage Platform E590, E790, E990</p> <p>Hitachi Virtual Storage Platform F350, F370, F700, F900</p> <p>Hitachi Virtual Storage Platform G350, G370, G700, G900</p> <p>Hitachi Virtual Storage Platform 5100, 5500, 5100H, 5500H MK-98RD9024</p> <p>Hitachi Virtual Storage Platform F400, F600, F800</p> <p>Hitachi Virtual Storage Platform G200, G400, G600, G800</p> <p>Hitachi Virtual Storage Platform N400, N600, N800</p> <p>Hitachi Virtual Storage Platform F1500</p> <p>Hitachi Virtual Storage Platform G1000, G1500 MK-92RD8072</p> <p>Performance Guide</p> <p>Hitachi Virtual Storage Platform E590, E790, E990</p> <p>Hitachi Virtual Storage Platform F350, F370, F700, F900</p> <p>Hitachi Virtual Storage Platform G350, G370, G700, G900</p> <p>Hitachi Virtual Storage Platform 5100, 5500, 5100H, 5500H MK-98RD9019</p> <p>Thin Image User Guide</p> <p>Hitachi Virtual Storage Platform E590, E790, E990</p> <p>Hitachi Virtual Storage Platform F350, F370, F700, F900</p> <p>Hitachi Virtual Storage Platform G350, G370, G700, G900</p> <p>Hitachi Virtual Storage Platform 5100, 5500,</p>	<p>■global-active device ユーザガイド</p> <p>■Performance Manager(Performance Monitor, Server Priority Manager, QoS) ユーザガイド</p> <p>■Thin Image ユーザガイド</p> <p>■Universal Replicator ユーザガイド</p> <p>■Hitachi Virtual Storage Platform E590, E790, E990: システム構築ガイド</p> <p>■Hitachi Virtual Storage Platform F350, F370, F700, F900 and Hitachi Virtual Storage Platform G350, G370, G700, G900: システム構築ガイド</p> <p>■Hitachi Virtual Storage Platform F400, F600, F800 and Hitachi Virtual Storage Platform G100, G200, G400, G600, G800: システム構築ガイド</p> <p>■Hitachi Virtual Storage Platform 5100, 5500, 5100H, 5500H: オープンシステム構築ガイド</p> <p>■Hitachi Virtual Storage Platform F1500 and Hitachi Virtual Storage Platform G1000,G1500: オープンシステム構築ガイド</p> <p>関連するドキュメントは次の URL をご参照ください。 http://itdoc.hitachi.co.jp/Pages/document_list/index.html</p>
--	---

5100H, 5500H

MK-98RD9020

Hitachi Virtual Storage Platform F400, F600, F800

Hitachi Virtual Storage Platform G200, G400,
G600, G800

Hitachi Virtual Storage Platform N400, N600,
N800

Hitachi Virtual Storage Platform F1500

Hitachi Virtual Storage Platform G1000, G1500

MK-92RD8011

Universal Replicator User Guide

Hitachi Virtual Storage Platform E590, E790,
E990

Hitachi Virtual Storage Platform F350, F370,
F700, F900

Hitachi Virtual Storage Platform G350, G370,
G700, G900

Hitachi Virtual Storage Platform 5100, 5500,
5100H, 5500H

MK-98RD9023

Hitachi Virtual Storage Platform F400, F600, F800

Hitachi Virtual Storage Platform G200, G400,
G600, G800

Hitachi Virtual Storage Platform N400, N600,
N800

Hitachi Virtual Storage Platform F1500

Hitachi Virtual Storage Platform G1000, G1500

MK-92RD8023

Provisioning Guide

Hitachi Virtual Storage Platform E590, E790,
E990

Hitachi Virtual Storage Platform F350, F370,
F700, F900

Hitachi Virtual Storage Platform G350, G370,
G700, G900

MK-97HM85026

Hitachi Virtual Storage Platform F400, F600, F800

Hitachi Virtual Storage Platform G200, G400,
G600, G800

Hitachi Virtual Storage Platform N400, N600,
N800

MK-94HM8014

	<p>Hitachi Vantara Support Connect, https://knowledge.hitachivantara.com/Documents</p>	
3	<p>Related documents</p> <p>The documents below are referenced in this document or contain more information about the features described in this document.</p> <p>Hitachi Vantara documents</p> <p>Hardware Reference Guide</p> <p>Hitachi Virtual Storage Platform E590, E790 MK-97HM85050</p> <p>Hitachi Virtual Storage Platform E990 MK-97HM85046</p> <p>Hitachi Virtual Storage Platform F350, F370 MK-97HM85016</p> <p>Hitachi Virtual Storage Platform F700 MK-97HM85017</p> <p>Hitachi Virtual Storage Platform F900 MK-97HM85018</p> <p>Hitachi Virtual Storage Platform G350, G370 MK-97HM85012</p> <p>Hitachi Virtual Storage Platform G700 MK-97HM85013</p> <p>Hitachi Virtual Storage Platform G900 MK-97HM85014</p> <p>Hitachi Virtual Storage Platform F400, F600 MK-94HM8045</p> <p>Hitachi Virtual Storage Platform F800 MK-94HM8046</p> <p>Hitachi Virtual Storage Platform G200 MK-94HM8020</p> <p>Hitachi Virtual Storage Platform G400, G600 MK-94HM8022</p> <p>Hitachi Virtual Storage Platform G800 MK-94HM8026</p> <p>Hitachi Virtual Storage Platform N400, N600 MK-94HM8053</p> <p>Hitachi Virtual Storage Platform N800 MK-94HM8054</p> <p>Hardware Guide</p>	<p>関連するドキュメントを次に示します。</p> <p>■Hitachi Virtual Storage Platform E590, E790, E990: ハードウェアリファレンスガイド</p> <p>■Hitachi Virtual Storage Platform F350, F370, F700, F900 and Hitachi Virtual Storage Platform G130, G150, G350, G370, G700, G900: ユーザガイド</p> <p>■Hitachi Virtual Storage Platform F400, F600, F800 and Hitachi Virtual Storage Platform G100, G200, G400, G600, G800: ユーザガイド</p> <p>■Hitachi Virtual Storage Platform F350, F370, F700, F900 and Hitachi Virtual Storage Platform G130, G150, G350, G370, G700, G900: システム構築ガイド</p> <p>Thin Image ユーザガイド</p> <p>システム管理者ガイド</p> <p>ハードウェアリファレンスガイド</p> <p>■Hitachi Virtual Storage Platform F400, F600, F800 and Hitachi Virtual Storage Platform G100, G200, G400, G600, G800: ユーザガイド</p> <p>■Hitachi Virtual Storage Platform E590, E790, E990: Storage Navigator ユーザガイド</p> <p>システム管理者ガイド</p> <p>■Hitachi Virtual Storage Platform 5100, 5500, 5100H, 5500H: Storage Navigator ユーザガイド</p>

	<p>Hitachi Virtual Storage Platform 5100, 5500, 5100H, 5500H MK-98RD9013</p> <p>Hitachi Virtual Storage Platform F1500 Hitachi Virtual Storage Platform G1000, G1500 MK-92RD8007</p> <p>System Administrator Guide</p> <p>Hitachi Virtual Storage Platform E590, E790, E990</p> <p>Hitachi Virtual Storage Platform F350, F370, F700, F900</p> <p>Hitachi Virtual Storage Platform G350, G370, G700, G900 MK-97HM85028</p> <p>Hitachi Virtual Storage Platform F400, F600, F800</p> <p>Hitachi Virtual Storage Platform G200, G400, G600, G800</p> <p>Hitachi Virtual Storage Platform N400, N600, N800 MK-94HM8016</p> <p>Hitachi Virtual Storage Platform 5100, 5500, 5100H, 5500H MK-98RD9009</p> <p>Hitachi Virtual Storage Platform F1500 Hitachi Virtual Storage Platform G1000, G1500 MK-92RD8016</p>	<p>■Hitachi Virtual Storage Platform F1500 and Hitachi Virtual Storage Platform G1000,G1500: Storage Navigator ユーザガイド</p>
4	<p>Comments</p> <p>Please send us your comments on this document to doc.comments@hitachivantara.com. Include the document title and number, including the revision level (for example, -07), and refer to specific sections and paragraphs whenever possible. All comments become the property of Hitachi Vantara LLC.</p> <p>Thank you!</p>	<p>本ドキュメントに関するご意見は、当社営業担当にご連絡ください。</p>
5	<p>Getting help</p> <p>Hitachi Vantara Support Connect is the destination for technical support of products and solutions sold by Hitachi Vantara. To contact technical support, log on to Hitachi Vantara Support Connect for contact information: https://support.hitachivantara.com/en_us/contact-us.html.</p> <p>Hitachi Vantara Community is a global online community for Hitachi Vantara customers, partners, independent software vendors,</p>	<p>本製品のサポート条件については、次の URL 内のサポート条件をご確認ください。</p> <p>http://www.hitachi.co.jp/products/it/unified/adapter/hbsdo/</p> <p>サポート契約をされているお客様は、次の連絡先にお問い合わせください。</p>

	<p>employees, and prospects. It is the destination to get answers, discover insights, and make connections. Join the conversation today!</p> <p>Go to community.hitachivantara.com, register, and complete your profile.</p>	<p>日立サポートサービス : http://www.hitachi-support.com/</p> <p>サポート契約をされていないお客様は、当社営業担当にお問い合わせください。</p>
6	<p>Release notes</p> <p>Read the release notes before installing and using this product. They may contain requirements or restrictions that are not fully described in this document or updates or corrections to this document. Release notes are available on Hitachi Vantara Support</p> <p>Connect: https://knowledge.hitachivantara.com/Documents.</p>	<p>次の URL をご参照ください。</p> <p>http://www.hitachi.co.jp/products/it/unified/adapter/hbsdo/</p>
7	<p>Hitachi Vantara</p> <p>Corporate Headquarters 2535 Augustine Drive Santa Clara, CA 95054 USA</p> <p>HitachiVantara.com community.HitachiVantara.com</p> <p>Contact Information USA: 1-800-446-0744 Global: 1-858-547-4526 HitachiVantara.com/contact</p>	<p>株式会社 日立製作所</p> <p>東京都千代田区丸の内一丁目 6 番 6 号</p>

免責事項、他社商標、輸出管理について

免責事項

本書の内容の一部、または全部を無断で複製することはできません。

本書の内容については、将来予告なしに変更することがあります。

本書に記載されている以外の方法で本製品を操作した結果、たとえ本製品がインストールされているお客様所有のコンピュータに何らかの障害が発生しても、当社は一切責任を負いかねますので、あらかじめご了承ください。

本製品のサポートサービスに関する詳細は、当社営業担当にお問い合わせください。

他社商標

すべてのブランド名および製品名は個々の所有者の登録商標または商標です。なお、本文中では®および™は明記しておりません。

輸出管理について

このドキュメントにより、提供された技術やプログラムまたは購入した製品を輸出(または非居住者への提供)する場合は、「外国為替および外国貿易法」その他適用される法令を遵守してください。